


---

---

---


---

---

---

---

---




---

---

---


---

---

---

---

---




---

---

---


---

---

---

---

---




---

---

---

---

---

---

---


---

---

---

---

---




---

---

---

---

---

---

---


---

---

---

---

---




---

---

---

---

---

---

---


---

---

---

---

---




---

---

---


---

---

---

---

---




---

---

---

---

---

---

---

---




---

---

---

---

---

---

---

---

72 TEMPERATURE SENSORS

**TECH TIP**

**Quick and Easy ECT Test**

To check that the wiring and the computer are functioning, regarding the ECT sensor, connect a scan tool and look at the ECT temperature display.

**STEP 1** Unplug the connector from the ECT sensor. The temperature displayed on the scan tool should read about -40.

**NOTE:** -40° Celsius is also -40° Fahrenheit. This is the point where both temperature scales meet.

**STEP 2** With the connector still removed from the ECT sensor, use a fused jumper lead and connect the two terminals of the connector together. The scan tool should display about 265°F (140°C). This same test procedure will work for the IAT and most other temperature sensors.

ALWAYS LEARNING Automotive Technology, Fifth Edition James Halderman PEARSON

---

---

---

---

---

---

---

---

---

---

72 TEMPERATURE SENSORS

**TECH TIP**

**Poor Fuel Economy? Black Exhaust Smoke? Look at the IAT**

If the intake air temperature sensor is defective, it may be signaling the computer that the intake air temperature is extremely cold when in fact it is warm. In such a case the computer will supply a mixture that is much richer than normal.

If a sensor is physically damaged or electrically open, the computer will often set a diagnostic trouble code (DTC). This DTC is based on the fact that the sensor temperature did not change for a certain amount of time, usually about 3 minutes. If, however, the wiring or the sensor itself has excessive resistance, a DTC will not be set and the result will be lower-than-normal fuel economy, and in serious cases, black exhaust smoke from the tailpipe during acceleration.

ALWAYS LEARNING Automotive Technology, Fifth Edition James Halderman PEARSON

---

---

---

---

---

---

---

---

---

---

72 TEMPERATURE SENSORS

**Figure 72-9** A typical temperature sensor circuit.

TEMPERATURE SENSOR HIGH RESISTANCE COLD LOWER RESISTANCE HOT

PCM 5V SIGNAL HIGHER VOLTAGE WHEN SENSOR IS COLD LOWER VOLTAGE WHEN SENSOR IS HOT

ALWAYS LEARNING Automotive Technology, Fifth Edition James Halderman PEARSON

---

---

---

---

---

---

---

---

---

---

72 TEMPERATURE SENSORS

**?** FREQUENTLY ASKED QUESTION

**What Exactly is an NTC Sensor?**

A negative temperature coefficient (NTC) thermistor is a semiconductor whose resistance decreases as the temperature increases. In other words, the sensor becomes more electrically conductive as the temperature increases. Therefore, when a voltage is applied, typically 5 volts, the signal voltage is high when the sensor is cold because the sensor has a high resistance and little current flows through to ground. ● **SEE FIGURE 72-8.**

However, when the temperature increases, the sensor becomes more electrically conductive and takes more of the 5 volts to ground, resulting in a lower signal voltage as the sensor warms.

ALWAYS LEARNING Automotive Technology, Fifth Edition James Halderman PEARSON

---

---

---

---

---

---

---

---