































FIGURE 10.8 A lateral acceleration sensor is usually located under the center console and can be easily checked by unbolting it and turning it on its side while monitoring the sensor value using a scan tool.



















