Electric and Hybrid Electric Vehicles, 1st Edition

Œ	
RT A	NSWER. Write the word or phrase that best completes each statement or answers the question.
1.	What actions are needed to disable the high-voltage (HV) circuit?
•	
2.	What are the personal safety precautions that service technicians should adhere to when servicing hybrid electric vehicles?
•	
	What are the recommended tools and equipment that should be used when working on the HV circuits of the HV c
-	
4.	What precautions should be taken when hoisting a hybrid or electric vehicle?
4.	What precautions should be taken when hoisting a hybrid or electric vehicle?
4.	What precautions should be taken when hoisting a hybrid or electric vehicle?
	What precautions should be taken when hoisting a hybrid or electric vehicle? When should the HV system be depowered?

Answer Key

Testname: EV1SHORT01

- 1. To safely depower the vehicle, always follow the instructions found in service information for the exact vehicle being serviced. The steps usually include the following:
 - STEP 1 Turn the ignition off and remove the key (if equipped) from the ignition and store it in a lock box to prevent accidental starting.

STEP 2 Remove the 12-volt power source to the HV controller and wait 10 minutes for all capacitors to discharge. This step could involve:

- Removing a fuse or a relay
- Disconnecting the negative battery cable from the auxiliary 12-volt battery

STEP 3 Remove the high-voltage fuse or service plug or switch.

STEP 4 Confirm there is no high-voltage power present before beginning the repair.

Page Ref: 9

- 2. The personal safety precautions that service technicians should adhere to when servicing hybrid or EV include:
 - Wear eye protection
 - Wear high-voltage gloves
 - Wear long sleeves
 - Wear insulted shoes or boots

Page Ref: 4-6

- 3. The recommended tools and equipment that should be used when working on the HV circuits of a hybrid or electric vehicle include:
 - Insulated rubber mats and blankets
 - Fire extinguishers
 - Some manufacturers recommend that a 10-foot insulated fiberglass pole be available outside the safety zone to be used to pull a technician away from the vehicle in the unlikely event of an accident where the technician is shocked or electrocuted.
 - CAT III rated digital multimeter
 - Megohmmeter (insulation tester)
 - Insulated hand tools

Page Ref: 5-6

4. When hoisting or using a floor jack, refer to the manufacturer's service information for proper lift points. Orange cables run under the vehicle just inside the frame rails on most hybrid and electric vehicles.

Page Ref: 9

- 5. If work is going to be performed on any of the following components, service information procedures must be followed to prevent possible electrical shock and personal injury.
 - HV battery pack
 - Any of the electronic controllers that use orange cables, such as the inverter and converters.
 - The air-conditioning compressor, if electrically driven, and has orange cables attached.

Page Ref: 9