

SENSOR	TYPICAL VALUE
Inside air temperature sensor	-40°F to 120°F (-40°C to 49°C)
Ambient air temperature sensor	-40°F to 120°F (-40°C to 49°C)
Engine coolant temperature (ECT) sensor	40°F to 250°F (-40°C to 121°C)
Sun load Sensor	0.3 volts (dark) 3.0 volts (bright)
Evaporator temperature sensor	Usually 34°F to 44°F (1°C to 7°C)
Relative Humidity sensor	0% to 100%