

Wheels: An e-mail from Chuck says, “I have a 1998 Ford Expedition with heated leather seats. The passenger side works great, but the driver’s side produces no heat at all. It does have power going to the switch because the indicator light illuminates. Any suggestions for a possible cure would be a warm welcome.”

Halderman: The most common cause of the heated seat not working is an open circuit (break in the circuit) that prevents current from flowing through the heating grid. The only fix is to replace the heating grid. This involves removing the seat fabric and replacing the element. The cost should be less than \$200.

