

Name _____

SHORT ANSWER. Write the word or phrase that best completes each statement or answers the question.

1) What is meant by lugging an engine?

2) How are the clutch and bell housing installed?

3) Why should the clutch, if equipped, be adjusted before starting the engine?

4) What should be done to help prevent rear cylinder distortion when the bell housing is being installed on the engine?

5) What is involved in "dressing the engine"?

Answer Key

Testname: SHORT 38

- 1) Lugging means increasing the throttle opening without increasing engine speed (RPM).
Page Ref: 451
- 2) The clutch and bell housing are often installed before installing the engine into the vehicle.
Page Ref: 448
- 3) Always adjust the clutch free play before starting the engine to help prevent engine thrust bearing or clutch release bearing damage.
Page Ref: 449
- 4) What should be done to help prevent rear cylinder distortion when the bell housing is being installed on the engine?
Page Ref: 449
- 5) "Dressing the engine" is a term used to describe the process of attaching all of the auxiliary items to the engine.
Page Ref: 449