

Automotive Electrical & Engine Performance 7/E


Chapter 29 Throttle Position (TP) SENSORS










Opening Your Class










KEY ELEMENT	EXAMPLES
Introduce Content	This course or class covers Automotive Electrical & Engine Performance . It correlates material to task lists specified by ASE and NATEF.
Motivate Learners	Explain how the knowledge of how something works translates into the ability to use that knowledge to figure why the engine does not work correctly and how this saves diagnosis time, which translates into more money.
State the learning objectives for the chapter or course you are about to cover and explain this is what they should be able to do as a result of attending this session or class.	Explain the chapter learning objectives to the students. <ol style="list-style-type: none">1. Discuss how throttle position sensors work.2. Describe how to test the TP sensor using a scan tool.3. Describe how the operation of the TP sensor affects vehicle operation.4. Discuss TP sensor rationality tests. This chapter will help you prepare for Engine Repair (A8) ASE certification test content area "E" (Computerized Engine Controls Diagnosis and Repair).
Establish the Mood or Climate	Provide a <i>WELCOME</i> , Avoid put downs and bad jokes.
Complete Essentials	Restrooms, breaks, registration, tests, etc.
Clarify and Establish Knowledge Base	Do a round robin of the class by going around the room and having each student give their backgrounds, years of experience, family, hobbies, career goals, or anything they want to share.

NOTE: This lesson plan is based on Automotive Electrical & Engine Performance 7/E Chapter Images found on Jim's web site @ www.jameshalderman.com

LINK CHP 29: [Chapter Images](#)

ICONS	Ch29 Throttle Position (TP) Sensors
	<p>1. SLIDE 1 CH29 Throttle Position (TP) Sensors</p> <p>Check for ADDITIONAL VIDEOS & ANIMATIONS @ http://www.jameshalderman.com/ WEB SITE REGULARLY UPDATED</p> <p><u>Videos</u></p> <p>At the beginning of this class, you can download the crossword puzzle & Word Search from the links below to familiarize your class with the terms in this chapter & then discuss them</p> <p>Crossword Puzzle (Microsoft Word) (PDF) Word Search Puzzle (Microsoft Word) (PDF)</p> <p>2. SLIDE 2 EXPLAIN Figure 29-1 typical TP sensor mounted on the throttle plate of this port-injected engine.</p> <p><u>DISCUSSION: PROVIDE THE STUDENTS WITH A WIRING DIAGRAM OF A TP CIRCUIT TO STUDY AND DISCUSS. WHAT IS THE FUNCTION OF EACH WIRE CONNECTED TO SENSOR?</u></p> <p><u>HANDS-ON TASK: HAVE STUDENTS LOCATE AND VISUALLY INSPECT A TP SENSOR FOR PROPER CONNECTION, ATTACHMENT, AND CONDITION.</u></p> <p>SOME TP SENSORS HAVE 4 WIRES. THE FOURTH WIRE IS COMMONLY A SWITCH CIRCUIT USED TO PROVIDE A SIGNAL THAT VEHICLE IS AT IDLE.</p> <p>SOME TP SENSORS GO BAD IN ONLY ONE SPOT—VEHICLES THAT ARE DRIVEN AT CONSTANT SPEEDS TEND TO WEAR THE TP IN ONE SPOT.</p> <p><u>ANIMATION: THROTTLE POSITION SENSOR (VIEW) (DOWNLOAD)</u></p>

ICONS	Ch29 Throttle Position (TP) Sensors
	<p>3. SLIDE 3 EXPLAIN Figure 29-2 The signal voltage from a throttle position increases as the throttle is opened because the wiper arm is closer to the 5-volt reference. At idle, the resistance of the sensor winding effectively reduces the signal voltage output to the computer.</p>
	<p><u>DISCUSSION: HAVE STUDENTS DISCUSS HOW TP SENSORS AFFECT AUTOMATIC TRANSMISSION FUNCTION. HOW COULD VARIOUS TP MALFUNCTIONS CAUSE ABNORMAL AUTOMATIC TRANSMISSION OPERATION?</u></p>
	<p>Throttle Position Volt Check Ref Signal (View) (Download)</p>
	<p>Throttle Position Ground Check (View) (Download)</p>
	<p>IF YOU FIND THAT TP SENSOR IS MISSING ITS VREF SIGNAL, CHECK OTHER SENSORS THAT OPERATE ON SAME VREF SIGNAL. IF OTHER SENSORS ARE ALSO MISSING THEIR VREF SIGNAL, THE PROBLEM MAY BE INSIDE THE COMPUTER.</p>
	<p>4. SLIDE 4 EXPLAIN Figure 29-3 A meter lead connected to a T-pin that was gently pushed along the signal wire of the TP sensor until the point of the pin touched the metal terminal inside the plastic connector.</p>
	<p>5. SLIDE 5 EXPLAIN Figure 29-4 typical waveform of a TP sensor signal as recorded on a DSO when the accelerator pedal was depressed with the ignition switch on (engine off). Clean transitions and the lack of any glitches in this waveform indicate a good sensor</p>
	<p>EXPLAIN TECH TIP</p> <p><u>DEMONSTRATION: SHOW HOW TO USE A DIGITAL VOLTMETER TO TEST TP SENSOR FOR PROPER OPERATION. BE SURE TO DEMONSTRATE PROPER TECHNIQUES THAT SHOULD BE USED TO PREVENT WIRE, TERMINAL, AND CONNECTOR DAMAGE DURING TESTING. FIGURE 29-5</u></p>
	<p>6. SLIDE 6 EXPLAIN FIGURE 29-5 Checking the 5-volt reference from the computer being applied to the TP sensor with the ignition switch on (engine off)</p> <p>7. SLIDE 7 EXPLAIN FIGURE 29-6 Checking voltage</p>

ICONS	Ch29 Throttle Position (TP) Sensors
	<p>drop between TP sensor ground & good engine ground with ignition on (engine off). A reading of greater than 0.2 volt (200 mV) represents a bad computer ground.</p>
	<p>WHEN USING A DIGITAL VOLTMETER, BE SURE METER IS NOT AUTORANGING; OTHERWISE, WHEN THE METER SWITCHES RANGES, IT CAN EASILY BE MISTAKEN AS A GLITCH IN SENSOR. <u>DEMONSTRATION: SHOW PROPER METHOD FOR ADJUSTING A TP SENSOR USING A VOLTMETER, DSO, OR SCAN TOOL</u></p>
	<p>ONLY EARLY MODEL TP SENSORS ARE ADJUSTABLE. CURRENT TP SENSORS ARE NOT ADJUSTABLE</p>
	<p>ON SOME OLDER VEHICLES, BASE IGNITION TIMING CANNOT BE SET UNLESS COMPUTER SEES AN IDLE SIGNAL FROM THE TP SENSOR. IT MAY BE NECESSARY TO ADJUST TP SENSOR AND/OR THROTTLE CABLE IN ORDER TO SET TIMING.</p>
	<p><u>HANDS-ON TASK: HAVE STUDENTS TEST A TP SENSOR FOR PROPER OPERATION USING A SCAN TOOL.</u></p>
	<p><u>Throttle Position Sensor</u> <u>Throttle Position Volt Check Ref Signal</u> <u>Throttle Position Ground Check</u></p>
	<p>EXPLAIN Testing Throttle Position Sensor USING DMM MIN/MAX FUNCTION EXPLAIN Testing Throttle Position Sensor USING SCAN TOOL EXPLAIN TP Sensor Diagnostic Trouble Codes</p>
	<p><u>ON-VEHICLE NATEF TASK INSPECT AND TEST THROTTLE POSITION SENSOR USING A GMM)/(DSO); PERFORM NECESSARY ACTION</u></p>
	<p><u>ON-VEHICLE NATEF TASK INSPECT & TEST PCM/ECM, ACTUATORS, & CIRCUITS USING GMM/DSO; PERFORM NECESSARY ACTION</u></p>