ter 12 ter 12	ve Technology 6th Edition 22 - Hydraulic Power Steering Systems 22
e	
RT A	ANSWER. Write the word or phrase that best completes each statement or answers the question.
1)) What are the five possible causes for hard steering?
2)) What is the procedure for flushing a power steering system?
3)) What is an integral power steering system?
4)) What tool is needed to remove and install a power steering pump pulley?
5)) How is a pressure test of a power steering system performed?

Answer Key

Testname: SHORT 122

- 1) Five possible causes of hard steering include:
 - a. Too tight an adjustment of the rack bushing or over-center adjustment
 - b. Under-inflated tires
 - c. Internal steering gear mechanical bending
 - d. Loose, worn or defective power steering pump drive belt
 - e. Low or contaminated power steering fluid

Page Ref: 1507-1508

- 2) Flushing a power steering system includes the following steps:
 - Step 1 Remove the low pressure hose from the pump (plug fitting) and direct the return line to an empty container. With the front wheels off the ground, fill the power steering pump reservoir and start the engine. Step 2 As the old power steering fluid is being pumped into the container, keep the reservoir full of clean fluid as an assistant turns the steering wheel.
 - Step 3 When the fluid is clean going into the container, stop the engine and reconnect the low pressure line to the pump.

Page Ref: 1508-1509

3) In an integral power steering system, the control valve and a power piston which applies force to the pitman arm are incorporated into the steering gear construction.

Page Ref: 1497

- 4) Most power steering pump service requires the removal of the pump from the engine mounting and/or removal of the drive pulley. A pulley removal/installation tool is used.

 Page Ref: 1511
- 5) Connect the pressure tester hoses to the power steering system following the manufacturer's instructions. Start the engine and close the shut off valve for a maximum of 15 seconds and observe the maximum pressure. Open the shutoff valve and repeat the test checking to see if the maximum pressures are all the same. Check service information for the procedures to follow if the pressures are not within specifications.

Page Ref: 1509-1510