

# Heated Glass Operation


Meets ASE Task: Meets ASE A6-G-1 (P2)- Diagnose comfort/convenience accessories.

Name \_\_\_\_\_ Date \_\_\_\_\_ Time on Task \_\_\_\_\_

Make/Model/Year \_\_\_\_\_ VIN \_\_\_\_\_ Evaluation: 4 3 2 1

\_\_\_\_\_ 1. Check service information for the specified testing procedures to follow when diagnosing an inoperative heated glass circuit.

\_\_\_\_\_  
\_\_\_\_\_



\_\_\_\_\_ 2. List the tools or equipment needed (check all that apply).

- \_\_\_\_\_ Digital voltmeter
- \_\_\_\_\_ Ohmmeter
- \_\_\_\_\_ Ammeter
- \_\_\_\_\_ Other (describe) \_\_\_\_\_

\_\_\_\_\_ 3. Based on the test results, what is the needed action? \_\_\_\_\_

\_\_\_\_\_  
\_\_\_\_\_