# **Automotive Fuel and Emissions Control Systems 4/E**

# **Chapter 23 Fuel Injection System Diagnosis & Service**

**Opening Your Class** 

KEY ELEMENT	EXAMPLES
Introduce Content	This course or class covers operation and service of <b>Automotive Fuel</b> and Emissions Control Systems. It correlates material to task lists specified by ASE and NATEF.
Motivate Learners	Explain how the knowledge of how something works translates into the ability to use that knowledge to figure why the engine does not work correctly and how this saves diagnosis time, which translates into more money.
State the learning objectives for the chapter or course you are about to cover and explain this is what they should be able to do as a result of attending this session or class.	<ol> <li>Explain the chapter learning objectives to the students.</li> <li>Explain the diagnosis of electronic fuel-injection systems.</li> <li>Describe how to test for an injector pulse.</li> <li>Understand the process of checking fuel-injector resistance.</li> <li>Explain how to scope-test fuel injectors and conduct pressure-drop balance and injector voltage-drop tests.</li> </ol>
Establish the Mood or Climate	Provide a WELCOME, Avoid put downs and bad jokes.
Complete Essentials	Restrooms, breaks, registration, tests, etc.
Clarify and Establish Knowledge Base	Do a round robin of the class by going around the room and having each student give their backgrounds, years of experience, family, hobbies, career goals, or anything they want to share.

NOTE: This lesson plan is based on Fuel & Emission Control 4<sup>th</sup> Edition Chapter Images found on Jim's web site @

www.jameshalderman.com

LINK CHP 23: Chapter Images

Ch23 Fuel Injection System Diagnosis & SVC

1. SLIDE 1 CH23 Fuel Injection System Diagnosis & Service

Check for ADDITIONAL VIDEOS & ANIMATIONS

@ <a href="http://www.jameshalderman.com/">http://www.jameshalderman.com/</a>
WEB SITE REGULARLY UPDATED

**VIDEOS** 

At the beginning of this class, you can download the crossword puzzle & Word Search from the links below to familiarize your class with the terms in this chapter & then discuss them

Crossword Puzzle (Microsoft Word) (PDF)
Word Search Puzzle (Microsoft Word) (PDF)

2. SLIDE 2 EXPLAIN Figure 23-1 If the vacuum hose is removed from the fuel-pressure regulator when the engine is running, the fuel pressure should increase. If it does not increase, then the fuel pump is not capable of supplying adequate pressure or the fuel-pressure regulator is defective. If gasoline is visible in the vacuum hose, the regulator is leaking and should be replaced

DEMONSTRATION: SHOW THE STUDENTS LOCATION OF FUEL RAIL AND PRESSURE REGULATOR ON A VEHICLE. POINT OUT VACUUM CONNECTIONS AT REGULATOR AND INTAKE MANIFOLDS. SHOW THEM FUEL INLET AND RETURN LINES AT FUEL RAIL. FIGURE 23-1

**EXPLAIN TECH-TIP** 

- **3. SLIDE 3 EXPLAIN FIGURE 23–2** (a) A fuel-pressure graph after key on, engine off (KOEO) on a TBI system.
- **4. SLIDE 4 EXPLAIN FIGURE 23–2** (b) Pressure drop after 10 minutes on a normal port fuel-injection system

**DISCUSSION:** DISCUSS PORT FUEL-INJECTED ENGINES. WHY IS A FUEL PRESSURE REGULATOR NEEDED? WHY MUST PRESSURE

# **Ch23 Fuel Injection System Diagnosis & SVC**














DIFFERENTIAL BETWEEN FUEL RAIL AND INTAKE MANIFOLD REMAIN CONSTANT?

DISCUSSION: DISCUSS POSITIVE CRANKCASE

VENTILATION SYSTEMS. WHAT PROBLEMS OR ISSUES CAN BE CAUSED BY A CLOGGED PCV SYSTEM? FIGURE 23-2 & 3

**5. SLIDE 5 EXPLAIN Figure 23-3** clogged PCV system caused engine oil fumes to be drawn into the air cleaner assembly. This is what the technician discovered during a visual inspection on this TBI system

DEMONSTRATION: SHOW GOOD & DEFECTIVE (OIL CONTAMINATED, BRITTLE, SOFT, OR DETERIORATED) VACUUM HOSES. SHOW HOW TO CHECK FOR INJECTOR OPERATION BY LISTENING FOR INJECTOR CLICKING WITH A STETHOSCOPE. DISCONNECT ONE INJECTOR TO SIMULATE A NONOPERATIVE CONDITION. FIGURE 23-4

DISCUSSION: DISCUSS VACUUM LEAKS.
WHAT EFFECT WILL A RUPTURED OR LEAKING
PRESSURE REGULATOR HAVE ON ENGINE
OPERATION? EXPLAIN THAT EXCESS FUEL CAN BE
DRAWN INTO THE INTAKE MANIFOLD, RESULTING
IN AN EXTREMELYRICH CONDITION THAT CAN
DAMAGE CATALYTIC CONVERTER.

### **EXPLAIN TECH-TIP**

- **6. SLIDE 6 EXPLAIN FIGURE 23–4** All fuel injectors should make the same sound with the engine running at idle speed. A lack of sound indicates a possible electrically open injector or a break in the wiring. A defective computer could also be the cause of a lack of clicking (pulsing) of the injectors.
- **7. SLIDE 7 EXPLAIN FIGURE 23–5** Fuel should be heard returning to the fuel tank at the fuel return line if the fuelpump and fuel-pressure regulator are functioning correctly.

### **EXPLAIN TECH-TIP**

**8. SLIDE 8 EXPLAIN Figure 23-6** Using scan tool to check for IAC counts or % as part of a diagnostic routine

# **Ch23 Fuel Injection System Diagnosis & SVC**

















**DISCUSSION:** HAVE THE STUDENTS DISCUSS NORMAL <u>IAC COUNTS</u>. WHAT DOES A VERY HIGH OR VERY LOW IAC COUNT (\_45 OR \_5) INDICATE? <u>FIGURE 23-6</u>

**EXPLAIN TECH-TIP** 

HANDS-ON TASK: USE ON-LINE SERVICE
INFORMATION TO LOOK UP FUEL PRESSURE
SPECIFICATIONS FOR THEIR OWN CARS.

ON-VEHICLE NATEF TASK: DIAGNOSE HOT OR COLD NO-STARTING, HARD STARTING, POOR DRIVEABILITY, INCORRECT IDLE SPEED, POOR IDLE, FLOODING, HESITATION, SURGING

- **9. SLIDE 9 EXPLAIN Figure 23-7** Checking the fuel pressure using a fuel-pressure gauge connected to the Schrader valve.
- **10. SLIDE 10 EXPLAIN Figure 23-8** Shutoff valves must be used on vehicles equipped with plastic fuel lines to isolate the cause of a pressure drop in the fuel system


DEMONSTRATION: DEMONSTRATE A FUEL PRESSURE TEST WITH A PRESSURE GAUGE CONNECTED TO FUEL RAIL AND A VACUUM GAUGE CONNECTED TO INTAKE VACUUM SOURCE. HOLD THROTTLE WIDE OPEN TO DEMONSTRATE LOW VACUUM AND ITS EFFECT ON FUEL PRESSURE. REMOVE VACUUM HOSE CONNECTED TO THE PRESSURE REGULATOR TO SHOW INCREASE IN FUEL PRESSURE. FIGURES 23-7 & 8

- 11. SLIDE 11 EXPLAIN Figure 23-9 (a) Noid lights are usually purchased as an assortment so that one is available for any type/size of injector wiring connector.
- **12. SLIDE 12 EXPLAIN Figure 23-9 (b)** Connector is unplugged from injector and a Noid light is plugged into harness side of connector. Noid light should flash when engine is being cranked if power circuit and the pulsing to ground by the computer are functioning normally.

<u>DEMONSTRATION:</u> INSTALL A <u>NOID LIGHT</u> IN INJECTOR HARNESS AND CRANK OR OPERATE ENGINE TO DEMONSTRATE LIGHT OPERATION FOR DIAGNOSIS. WHAT CAN CAUSE A NOID LIGHT NOT

# **Ch23 Fuel Injection System Diagnosis & SVC**







- **13. SLIDE 13 EXPLAIN Figure 23-10** Use DMM set to read DC volts to check the voltage drop of the positive circuit to the fuel injector. A reading of 0.5 volt or less is generally considered to be acceptable
- **14. SLIDE 14 EXPLAIN Figure 23-11** An ohmmeter is connected to the injector electrical terminals to read injector coil resistance.





DEMONSTRATION: SHOW HOW TO CHECK INJECTOR RESISTANCE WITH OHMMETER. HEAT INJECTOR WITH A HEAT GUN & THEN RECHECK RESISTANCE TO DEMONSTRATE HEAT RELATED CHANGE. FIGURE 23-11 ALSO SHOW VOLTAGE DROP METHOD IN FIGURE 23-10 QUICK CHECK INJECTOR PLUSE (VIEW) (DOWNLOAD) OUICK CHECK INJECTOR VOLTS (VIEW) (DOWNLOAD)













SOME VEHICLES ARE DESIGNED TO SHUT DOWN INJECTORS INDIVIDUALLY, OR IN GROUPS THAT CAN CAUSE A NO-START CONDITION, TO PROTECT PCM CIRCUITRY IF CURRENT IS TOO HIGH.


DISCUSSION: DISCUSS RELATIONSHIP
BETWEEN RESISTANCE AND AMPERAGE
(OHM'S LAW). HOW DOES A CHANGE IN

RESISTANCE AFFECT INJECTOR OPERATION? HOW CAN A DECREASE IN RESISTANCE CAUSE DAMAGE TO INJECTOR DRIVE CIRCUITRY?

DEMONSTRATION: SHOW HOW TO DISCONNECT INJECTORS & CHECK FOR RESISTANCE. REMIND STUDENTS THAT RESISTANCE WILL CHANGE AS INJECTOR TEMPERATURE CHANGES. AN INFRARED THERMOMETER CAN BE USED TO CHECK INJECTOR TEMPERATURE AND COMPARE RESISTANCE SPECS FIGURES 23-11, 12, & 13

# **Ch23 Fuel Injection System Diagnosis & SVC**







### **TEST INJECTOR RESISTANCE (VIEW) (DOWNLOAD)**







DISCUSSION: TALK ABOUT A PRESSURE-DROP BALANCE TEST. WHAT HAPPENS TO FUEL DELIVERY IF AN INJECTOR IS RESTRICTED? HOW WILL CHANGE IN AIR/FUEL MIXTURE IN 1 CYLINDER AFFECT ENGINE OPERATION?



**16. SLIDE 16 EXPLAIN Figure 23-13 (a)** meter is connected to read one group of "3" 12-ohm injectors. Result should be 4 ohms & this reading is little low indicating that at least 1 injector is shorted (low resistance).





### **EXPLAIN TECH-TIP**



18. SLIDE 18 EXPLAIN Measuring Resistance of Individual Injectors & EXPLAIN Figure 22-14 If an injector has specified resistance, this does not mean that it is okay. This injector had specified resistance yet it did not deliver correct amount of fuel because it was clogged



DEMONSTRATION: SHOW EXAMPLES OF GOOD AND BAD INJECTORS. REMIND THEM THAT INJECTOR SPRAY PATTERNS CANNOT BE DETERMINED BY A VISUAL INSPECTION OF INJECTOR ALONE. FIGURE 23-14

# **Ch23 Fuel Injection System Diagnosis & SVC**

























**19. SLIDE 19 EXPLAIN Figure 23-15** After connecting a pressure gauge, unplug the electrical connector from an injector and attach test lead from the pulse unit to injector

DEMONSTRATION: PERFORM AN INJECTOR PRESSURE BALANCE TEST. INSERT A CHECK BALL FROM A CARBURETOR OR AUTOMATIC TRANSMISSION INTO AN INJECTOR INLET PRIOR TO PERFORMING A BALANCE TEST WITH A SIMULATED PLUGGED OR RESTRICTED INJECTOR. FIGURE 23-15

**20. SLIDE 20 EXPLAIN** Injector Voltage-Drop Tests & **EXPLAIN Figure 23-16** An injector tester being used to check the voltage drop through the injector while the tester is sending current through the injectors. This test is used to check the coil inside the injector. This same tester can be used to check for equal pressure drop of each injector by pulsing the injector on for 500 ms

## <u>DEMONSTRATION:</u> PERFORM A VOLTAGE-DROP TEST ACROSS INJECTORS. <u>FIGURE</u> 23-16

DISCUSSION: HAVE THE STUDENTS TALK ABOUT VOLTAGE-DROP TESTS. WHY IS THE VOLTAGE DROP ACROSS THE INJECTORS IMPORTANT? WHAT PROBLEMS OR SYMPTOMS WOULD BE PRESENT IF VOLTAGE DROP WAS HIGHER ACROSS ONE INJECTOR? FIGURE 23-16

- **21. SLIDE 21 EXPLAIN** Scope-Testing Fuel Injectors & **EXPLAIN Figure 23-17** A digital storage oscilloscope can be easily connected to an injector by carefully back probing the electrical connector.
- **22. SLIDE 22 EXPLAIN Figure 23-18** injector on-time is called the pulse width

<u>DEMONSTRATION:</u> DISPLAY INJECTOR DRIVE CIRCUIT WAVEFORM USING AN OSCILLOSCOPE. AFTER DISPLAYING WAVEFORM, MEASURE INJECTOR RESISTANCE. <u>FIGURES 23-17 & 18</u>

**23. SLIDE 23 EXPLAIN Figure 23-19** A typical peakand-hold fuel-injector waveform. Most fuel injectors that measure less than 6 ohms will usually display a similar waveform

# **Ch23 Fuel Injection System Diagnosis & SVC**





















DEMONSTRATION: WITH A SCOPE CONNECTED TO AN INJECTOR DRIVE CIRCUIT, SHOW HOW PCM CONTROLS FUEL MIXTURE BY CHANGING INJECTOR ON-TIME WITH THE COOLANT TEMPERATURE SENSOR SIGNAL WIRE OPEN AND GROUNDED. THIS PROCESS ALLOWS PCM TO THINK THE ENGINE IS OPERATING AT TEMPERATURE EXTREMES, SO IT CHANGES FUEL MIXTURE ACCORDINGLY. FIGURE 23-19

DISCUSS FREQUENTLY ASKED QUESTION

**24. SLIDE 24 EXPLAIN FIGURE 23–20** set of 6 reconditioned injectors. The sixth injector is barely visible at the far right

**ON-VEHICLE NATEF TASK** INSPECT AND TEST FUEL INJECTORS.

ON-VEHICLE NATEF TASK FUEL INJECTOR BALANCE TEST

**ON-VEHICLE NATEF TASK** INJECTOR VOLTAGE WAVEFORM TEST.

DISCUSSION: HAVE THE STUDENTS TALK ABOUT IDLE AIR SPEED CONTROL. WHAT IS CONTROLLED BY INCREASING OR DECREASING AMOUNT OF AIR BYPASSING THROTTLE PLATE?

- **25. SLIDE 25 EXPLAIN Figure 23-21** IAC controls idle speed by controlling amount of air that passes around throttle plate. More airflow results in higher idle speed.
- **26. SLIDE 26 EXPLAIN Figure 23-22** A typical IAC.
- **27. SLIDE 27 EXPLAIN Figure 23-23** Some IAC units are purchased with the housing as shown. Carbon buildup in these passages can cause a rough or unstable idling or stalling.

<u>DEMONSTRATION:</u> SHOW EXAMPLES OF <u>IDLE</u>
<u>AIR CONTROL VALVES.</u> CONNECT IDLE AIR
CONTROL VALVE TO 12 VOLT SOURCE TO
DEMONSTRATE OPERATION <u>FIG 23-21, 22, & 23</u>

# **Ch23 Fuel Injection System Diagnosis & SVC**





**28. SLIDE 28 EXPLAIN FIGURE 23–24** (a) Nothing looks unusual when the hood is first opened. (b) When the cover is removed from the top of the engine, a mouse or some other animal nest is visible. The animal had already eaten through a couple of injector wires. At least the cause of the intermittent misfire was discovered




<u>DEMONSTRATION:</u> CONNECT <u>SCAN TOOL</u> TO A VEHICLE & <u>OPERATE IDLE AIR CONTROL</u>

<u>VALVE</u> TO DEMONSTRATE ITS OPERATION. SHOW STUDENTS IDLE AIR COUNTS AS DISPLAYED ON SCAN TOOL.



HANDS-ON TASK: HAVE STUDENTS REMOVE
THROTTLE BODY FROM THEIR OWN CARS AND
INSPECT THE IDLE AIR CONTROL VALVE PASSAGES
FOR DEPOSITS, CLEANING AS NECESSARY.
THROTTLE BODIES SHOULD BE REMOVED &
CLEANED PERIODICALLY TO ENSURE PROPER
ENGINE IDLE SPEEDS.







**30. SLIDE 30 EXPLAIN Figure 23-26** Testing fuel-pump volume using a fuel-pressure gauge with a bleed hose inserted into a suitable container. The engine is running during this test



DEMONSTRATION: DEMONSTRATE TESTING OF FUEL PUMP VOLUME WITH A PRESSURE GAUGE CONNECTED TO A RUNNING ENGINE. FIGURES 23-25 & 26



SAFETY FUEL LEAKS FROM IMPROPERLY INSTALLED TEST EQUIPMENT CAN BE CATASTROPHIC. EMPHASIZE SAFETY BY DEMONSTRATING CHECKS FOR FUEL LEAKS WITH A TESTER INSTALLED, THE KEY ON, & ENGINE OFF. REMIND STUDENTS TO HAVE A FIRE EXTINGUISHER AVAILABLE BEFORE STARTING A TEST.

# **Ch23 Fuel Injection System Diagnosis & SVC**










- 31. SLIDE 31 EXPLAIN Figure 23-27 Testing fuel-pump volume using a fuel pressure gauge with a bleed hose inserted into a suitable container
- 32. SLIDE 32 EXPLAIN Figure 23-28 typical two-line cleaning machine hookup, showing an extension hose that can be used to squirt a cleaning solution into the throttle body while the engine is running on the cleaning solution and gasoline mixture. Typical two-line cleaning machines include Carbon Clean, Auto Care, Injector Test, DeCarbon, or Motor-Vac.
- **33. SLIDE 33 EXPLAIN Figure 23-29** To thoroughly clean a throttle body, it is sometimes best to remove it from the vehicle







**DISCUSSION:** DISCUSS FUEL TRIM VALUES. WHAT HAPPENS TO LONG TERM FUEL TRIM WHEN **SHORT-TERM FUEL TRIM REACHES ITS REDUCTION LIMIT? WHAT HAPPENS WHEN SHORT-TERM FUEL** TRIM REACHES ENRICHMENT LIMIT? WHAT HAPPENS WHEN LONG-TERM FUEL TRIM REACHES **ITS CORRECTION LIMITS?** 



**EXPLAIN TECH-TIP** 



- 34. SLIDE 34 EXPLAIN Figure 23-30 amount each injector is able to flow is displayed in glass cylinders are each injector for a quick visual check.
- **35. SLIDE 35 EXPLAIN Figure 23-31** line that has the yellow tag is a high pressure line and this line must be replaced with new part if removed even for a few minutes to gain access to another part.

# **Ch23 Fuel Injection System Diagnosis & SVC**













DEMONSTRATION: CONNECT A SCAN TOOL TO A RUNNING ENGINE SO STUDENTS CAN VIEW LONG & SHORT-TERM FUEL TRIM VALUES.
CREATE RICH & LEAN CONDITIONS BY USING PROPANE ENRICHMENT & CREATING VACUUM OR AIR LEAKS. SHOW STUDENTS FUEL TRIM CORRECTIONS AS THE MIXTURE CHANGES.
DEMONSTRATION: SHOW THE STUDENTS HOW TO FIND THE FUEL PUMP RELAY USING A COMPONENT LOCATOR.

WHEN OEM DOES NOT PROVIDE IDENTIFICATION INFORMATION ON COVER OF RELAY BOX, RELAYS MUST BE LOCATED AND IDENTIFIED USING AN ELECTRICAL COMPONENT LOCATOR.

**36. SLIDES 36-65 FUEL INJECTION DIAGNOSIS SLIDE SHOW**