
Automotive Electrical & Engine Performance 8/E Chapter 24 Air Management

Opening Your Class

KEY ELEMENT	EXAMPLES
Introduce Content	This Automotive Electrical & Engine Performance 8th edition provides complete coverage of automotive areas pertaining vehicle electrical systems and engine performance. It correlates material to task lists specified by ASE and ASEEducation (NATEF) and emphasizes a problem-solving approach. Chapter features include Tech Tips, Frequently Asked Questions, Case Studies, Videos, and Animations that are listed in this Lesson Plan. This Lesson Plan also references ASEEducation (NATEF) Task Sheets available from Jim's web site.
Motivate Learners	Explain how the knowledge of how something works translates into the ability to use that knowledge to figure why the engine does not work correctly and how this saves diagnosis time, which translates into more money.
State the learning objectives for the chapter or course you are about to cover and explain this is what they should be able to do as a result of attending this session or class.	 Explain learning objectives to students as listed below: 1. Discuss the different components of an air management system. 2. Explain airflow control and air temperature control in an A/C system. 3. Discuss air filtration, air ducts, and plenum and control doors. 4. Explain nonelectrical and electronic HVAC controls. Prepare for the ASE Heating and Air Conditioning (A7) certification test content area "B" (Refrigeration System Component Diagnosis and Repair).
Establish the Mood or Climate	Provide a WELCOME , Avoid put downs and bad jokes.
Complete Essentials	Restrooms, breaks, registration, tests, etc.
Clarify and Establish	Do a round robin of the class by going around the room and having
Knowledge Base	each student give their backgrounds, years of experience, family, hobbies, career goals, or anything they want to share.

NOTE: This lesson plan is based on Automotive Electrical & Engine Performance 8th Edition Chapter Images found on Jim's web site @ <u>www.jameshalderman.com</u>

DOWNLOAD Chapter 24 Chapter Images: From http://www.jameshalderman.com/books_a8.html#anchor2





CH24 AIR MANAGEMENT

1. SLIDE 1 Chapter 24 AIR MANAGEMENT

Check for ADDITIONAL VIDEOS & ANIMATIONS @ <u>http://www.jameshalderman.com/</u> WEB SITE IS CONSTANTLY UPDATED

Videos

At the beginning of this class, you can download the crossword puzzle & Word Search from Jim's web site to familiarize your class with terms in this chapter & then discuss them, see below:

http://www.jameshalderman.com/books_a8.html#an chor2

DOWNLOAD

Crossword Puzzle (Microsoft Word) (PDF) Word Search Puzzle (Microsoft Word) (PDF

- 2. SLIDE 2 EXPLAIN FIGURE 24–1 HVAC airflow is directed toward the windshield, dash or floor vents, or combinations, depending on the system settings.
- **3. SLIDE 3 EXPLAIN FIGURE 24–2** three major portions of the A/C and heat system are air inlet, plenum, and air distribution. The shaded portions show the paths of four control doors.
- 4. SLIDE 4 EXPLAIN FIGURE 24–3 In defog or defrost mode position, the air is directed through the evaporator to remove the moisture from the air before being sent through the heater core to warm the air.
- **5. SLIDE 5 EXPLAIN FIGURE 24–4** Most HVAC control heads include a control for turning units on and setting the mode of operation, a control for adjusting the temperature, and a control for the fan speed.

DISCUSS FREQUENTLY ASKED QUESTION: What Does the Snowflake Button on the Dash Do? Some people, such as those who drive vehicles that are equipped with automatic climate control systems, sometimes find it

ICONS	CH24 AIR MANAGEMENT
	hard to figure out how to engage A/C
	compressor on a rental car or a vehicle that
	they have not driven before. Often the driver
	turns the fan to high and the mode selector to
	the dash vent position, but no cool air is being
	delivered. For the compressor to function, the
	button that looks like a snowflake has to be
	pushed. The snowflake button is actually the
	air-conditioning on/off button. • SEE FIGURE
	24–5.
	6. SLIDE 6 EXPLAIN FIGURE 24–5 A/C compressor is turned on or off by depressing "snowflake" button on the
	dash.
	7. SLIDE 7 EXPLAIN FIGURE 24–6 Many air control doors swing on their upper and lower pivots, in red.
	 8. SLIDE 8 EXPLAIN FIGURE 24–7 (a) A typical rolling-
	door type HVAC door that is shown almost fully closed.
	(b) The same door is shown about half open.
	9. SLIDE 9 EXPLAIN FIGURE 24–8 The blower motor
	forces air to flow through the A/C evaporator to remove
	moisture from the air before it is sent through the heater
	core where the air is heated before being directed to the defrost and floor vents.
	10. SLIDE 10 EXPLAIN FIGURE 24–9 An extremely dirty cabin filter removed from a Subaru Legacy. The
	owner had complained about a lack of airflow from the
	air-conditioning vents. A new cabin filter Corrected
	concern.
	EXPLAIN TECH TIP: Keep the Air Screen Clean
	The outside air inlet screen must be kept in good
	condition to prevent debris and small animals from
	entering the HVAC case Leaves and pine needles
	can enter, decay, and mold. Mice have been known
	to enter and build nests and/or die. Any of these
	conditions can create a bad smell and are very
	difficult to clean.
	11. SLIDE 11 EXPLAIN FIGURE 24–10 A typical HVAC housing that often has to be removed from vehicle as an
	assembly to get access to the heater core and evaporator.

ICONS	CH24 AIR MANAGEMENT
	12. SLIDE 12 EXPLAIN FIGURE 24–11 The air inlet to the HVAC system is usually at the base of the windshield and covered with a plastic screen (grille) to help keep debris, such as leaves, from entering the system.
	13. SLIDE 13 EXPLAIN FIGURE 24–12 (a) The temperature and mode doors swing to direct all of the cool air past the heater core, (b) through the core to become hot, (c) or to blend hot and cool air.
	DISCUSSION: Host a discussion on the operation of the blend doors. What kind of concerns could take place?
	14. SLIDE 14 EXPLAIN FIGURE 24–13 (a) In a blend-air system, all of the air is cooled. Then some of it is reheated and blended with the cool air to get the right temperature. (b) In a reheat system, all of the air is cooled and then reheated to the correct temperature.
	15. SLIDE 15 EXPLAIN FIGURE 24–14 Ducts are placed in the center console or on the floor under the front seats to provide heated and cooled air to the rear seat passengers.
	16. SLIDE 16 EXPLAIN FIGURE 24–15 (a) (With no vacuum signal, the spring extends the actuator shaft to place the door in a certain position. (b) A vacuum signal pulls the shaft inward and moves the door to the other position.
	 17. SLIDE 17 EXPLAIN FIGURE 24–16 Many older vehicles used vacuum actuators to move the HVAC doors. When vacuum actuators operate, they alter air–fuel mixture in the engine. Because vacuum controls affect engine operation and, therefore, emissions, recent vehicles use electric control systems.
	DISCUSSION: Host a discussion on the operation
	of the pneumatic blend doors. What kind of concerns could take place?
	18. SLIDE 18 EXPLAIN FIGURE 24–17 Three compact, electric actuators/servomotors operate the doors in this part of the HVAC case.
	19. SLIDE 19 EXPLAIN FIGURE 24–18 two-wire HVAC electronic actuator where the direction of rotation is controlled by the HVAC control head or module, which

ICONS	CH24 AIR MANAGEMENT
	changes the direction of rotation by changing the polarity
	of the power and ground connection at the motor.
	EXPLAIN TECH TIP: Defrost All the Time? Check
3-5	the Vacuum: A common problem with older
	vehicles that use vacuum actuators involves
	airflow from the defroster ducts, even though
	selector lever is in other positions. The defrost
	setting is the default position in the event of a
	failure with the vacuum supply. The defrost
	position is used because it is the safest position.
	For safety, the windshield musts remain free from
	frost. Heat is also supplied to the passenger
	compartments not only through defrost ducts, but
	also through the heater vents at floor level. <i>If</i>
	airflow is mostly directed to the windshield, check
	under the hood for a broken, disconnected, or
	missing vacuum hose. Check the vacuum reserve
	container for cracks or rust (if metal) that could
	prevent the container from holding vacuum. Check
	all vacuum hose connections at the intake manifold
	and trace each carefully, inspecting for cracks,
	splits, or softened areas that may indicate a
	problem.
	NOTE: This problem of incorrect airflow inside
	vehicle often occurs after another service
	procedure has been performed, such as air filter or
	cabin filter replacement. The movement of the
	technician's body and arms can cause a hose to be
	pulled loose or a vacuum fitting to break without
	the service technician being aware that anything
	wrong has occurred.
	20. SLIDE 20 EXPLAIN FIGURE 24–19 Three-wire actuators include a logic chip inside motor assembly. The HVAC control module then sends a 0-volt to 5-volt signal to the motor assembly to control the direction of rotation.
	21. SLIDE 21 EXPLAIN FIGURE 24–20 A typical five- wire HVAC actuator showing the two wires used to power the motor and the three wires used for the motor position potentiometer.

ICONS	CH24 AIR MANAGEMENT
	Blower (View) (Download)
≥1111ii	Blower Control, Manual (View) (Download)
	Blower Control, PWM (View) (Download)
	Diower Control, P WW (View) (Download)
	22. SLIDE 22 EXPLAIN FIGURE 24–21 squirrel cage blower motor. A replacement blower motor usually does not come equipped with the squirrel cage blower, so it has to be switched from the old motor.
	DISCUSSION: Have the students discuss
QUESTION	methods used to control blower motor speed. What usually causes failure of high-speed fuse on relay?
	23. SLIDE 23 EXPLAIN FIGURE 24–22 EXPLAIN A blower motor circuit with four speeds controlled ng resistors. The three lowest fan speeds (low, medium-low, and medium high) use the blower motor resistors to drop the voltage to the motor and reduce current to the motor. On high, the resistors are bypassed. The "high" position on the fan switch energizes a relay, which supplies the current for the blower on high through a fusible link or maxi fuse.
	24. SLIDE 24 EXPLAIN FIGURE 24–23 EXPLAIN A blower motor resistor pack used to control blower motor speed. Some blower motor resistors are flat and look like a credit card and are called "credit card resistors.
	25. SLIDE 25 EXPLAIN FIGURE 24–24 EXPLAIN A brushless DC motor that uses the body computer to control the speed.
	26. SLIDE 26 EXPLAIN IGURE 24–25 EXPLAIN Using a mini AC/DC clamp-on multimeter to measure the current drawn by a blower motor.
	DEMONSTRATION: Show the students how to
DEMO	properly test blower motor resistor packs using a DMM
	HANDS-ON TASK: Provide the students with a blower motor circuit complaint and a wiring diagram of the circuit. Have them determine possible causes, using only their knowledge of circuit operation and the wiring diagram. Grade students on their ability to narrow down possible causes without performing circuit tests.

ICONS	CH24 AIR MANAGEMENT
DEMO	DEMONSTRATION: Show the students how to use a voltmeter to measure voltage drop throughout a blower motor circuit.
<mark>₩</mark>	HANDS-ON TASK: Have the students locate, inspect, and test a blower motor using common test equipment.
and the second se	DEMONSTRATION: DEMO BELOW
DEMO	ASEEDUCATION TASKS
	ASEEDUCATION D1 TASK: Inspect and test
	HVAC system blower motors, resistors, switches,
-0-0	relays, wiring, and protection devices; determine
Education Foundation	needed action.
L L	ASEEDUCATION D3 TASK: Diagnose
	malfunctions in the vacuum, mechanical, and
-0- 8	electrical components and controls of the heating,
Education Foundation	ventilation, and A/C (HVAC) system; determine
Concación Poundación	needed action.
	ASEEDUCATION D4 TASK: Inspect and test
	HVAC system control panel assembly; determine needed action.
	ASEEDUCATION D5 TASK Inspect and test
Ass Education Foundation	HVAC system control cables, motors, and linkages;
	perform needed action.
	ASEEDUCATION D6 TASK. Inspect HVAC
	system ducts, doors, hoses, cabin filters, and
	outlets; perform needed action.
	ASEEDUCATION D7 TASK. Identify the source
	of HVAC system odors.