


Measuring Systems And Tools

Chapter 7



<http://jameshalderman.com>

ACROSS

- Another name for the barrel of a micrometer is a _____.
- Another name for a small-hole gauge is a _____-_____.
- A _____ is an expensive, but important, gauge used to measure cylinder taper and out-of-round as well as main bearing bore for taper and out-of-round.
- Every revolution of the thimble moves the _____ 0.025 in.
- A _____ caliper is normally used to measure length, inside and outside diameters, and depth.
- A _____ is an accurately manufactured strip of metal that is used to determine the gap or clearance between two components.
- A _____ is a precision ground metal measuring gauge that is used to check the flatness of engine components when used with a feeler gauge.
- A _____ is similar to a conventional micrometer except that it is designed to measure the depth from a flat surface.

DOWN

- A _____ is normally used to measure length, inside and outside diameters, and depth.
- Velocity, torque, and power are examples of _____ units.
- Another name for a feeler gauge is a _____.
- A _____ is used with a micrometer to measure the inside diameter of a hole or bore.
- The _____ customary measuring system was established about 1100 A.D. in England during the reign of Henry I.
- Most of the world uses the _____ of measure.
- The _____ rotates over the sleeve on a screw that has 40 threads per inch.
- A _____ weighs about 1 gram.
- A _____ is a precision measuring instrument used to measure crankshaft end play, crankshaft runout, and valve guide wear.
- A _____ is the most used measuring instrument in engine repair service.
- A _____ gauge is used with a micrometer to measure the inside of small holes.
- All micrometers should be checked and calibrated as needed using a _____.