


Rear Suspension And Service

Chapter 113



<http://jameshalderman.com>

ACROSS

- 1 A rear strut system is often referred to as a _____ suspension by European manufacturers and engineers.
- 4 A _____ suspension is a simple system because it does not require control arms to brace the position the axle.
- 6 Most rear-wheel-drive trucks use a solid rear axle with leaf springs in an arrangement called a _____.
- 10 A trailing arm rear suspension on a nondriven solid axle virtually always includes a _____.
- 11 A _____ can be used at the rear of either a rear-wheel-drive or front-wheel-drive vehicle.
- 13 A _____ extends from a frame crossmember located ahead of the rear axle back to the axle housing or a wheel knuckle.
- 16 Rear suspension service starts with a thorough test-drive, to observe any unusual noises or _____ that may be caused by a fault with a rear suspension component.
- 17 On a front-wheel-drive vehicle, a solid axle is usually a simple, _____ or tubular beam that may contain a torsion bar, rod, or tube to allow some twisting action.
- 18 _____ is a product of the law of physics, which states that every action produces an equal and opposite reaction.

DOWN

- 2 A _____ is similar to a trailing arm in that it extends back from a frame member to the axle.
- 3 A _____ suspension is used only at a nondriven rear axle.
- 5 _____ can be used to level the vehicle while towing a trailer or when heavily loaded.
- 7 The _____ of the frame and body must be heavy to oppose the unsprung weight of a solid axle, especially on a driven axle.
- 8 Another name for a track rod is a _____.
- 9 The Ford axle centering pivot bracket and linkage is called a _____.
- 10 The main benefit of an SLA suspension is that it reduces _____ and improves traction.
- 12 On a few models, especially those with a high-performance suspension, a _____ provides additional resistance to axle windup.
- 14 If engine torque is applied to the rear axle to drive the vehicle the axle is referred to as a _____.
- 15 The use of _____ has grown dramatically over the past several decades to the point where such systems are now fairly common.